

Zoznam podporovaných zariadení pre DIGI GO

Značka	OS / Platforma	Telefón / Zariadenie
Acer	Android	S57
Acer	Android	Liquid Z530 (T02)
Acer	Android	Liquid Jade Z
Alcatel	Android	One Touch 2045X
Alcatel	Android	ONE TOUCH IDOL 6030X
Alcatel	Android	ONETOUCH IDOL S
Apple	iOS	iPhone 3G
Apple	iOS	iPhone 3GS
Apple	iOS	iPhone 4
Apple	iOS	iPhone 4S
Apple	iOS	iPhone 5
Apple	iOS	iPhone 5C
Apple	iOS	iPhone 5S
Apple	iOS	iPhone 6
Apple	iOS	iPhone 6 Plus
Apple	iOS	iPhone 6S
Apple	iOS	iPhone 6S Plus
Apple	iOS	iPhone 7
Apple	iOS	iPhone 7 Plus
Apple	iOS	iPhone SE
Apple	iOS	iPhone 8
Apple	iOS	iPhone 8 Plus
Apple	iOS	iPhone X
Apple	iOS	iPad WiFi
Apple	iOS	iPad WiFi + 3G
Apple	iOS	iPad 2
Apple	iOS	iPad 2 WiFi
Apple	iOS	iPad 2 WiFi + 3G
Apple	iOS	iPad 3 WiFi
Apple	iOS	iPad 3 WiFi + 3G
Apple	iOS	iPad 4 WiFi
Apple	iOS	iPad 4 WiFi + 3G
Apple	iOS	iPad Mini WiFi
Apple	iOS	iPad Mini WiFi + 3G
Apple	iOS	iPad Mini 2
Apple	iOS	iPad Mini 3
Apple	iOS	iPad Mini 4
Apple	iOS	iPad Air
Apple	iOS	iPad Air 2
Apple	iOS	iPad Pro
ASUS	Android	EEE Pad
ASUS	Android	Zenfone AR
ASUS	Android	Zenfone 4 Pro
ASUS	Android	Zenfone 4 Selfie Pro

ASUS	Android	Zenfone 4
ASUS	Android	Zenfone 3 Deluxe
ASUS	Android	Zenfone Zoom S
ASUS	Android	Zenfone 3
ASUS	Android	Zenfone Max plus
ASUS	Android	Zenfone 4 selfie
ASUS	Android	Zenfone 3 Max
ASUS	Android	Zenfone 4 Max
ASUS	Android	Zenfone Live
ASUS	Android	Zenfone Go
Caterpillar	Android	Cat S30
Caterpillar	Android	Cat S60
Coolpad	Android	Coolpad Porto S
Gigabyte	Android	G SMART GS202
Gigabyte	Android	G SMART Rio R1
Google	Android	Pixel 2 XL
Google	Android	Pixel 2
Google	Android	Pixel
Google	Android	Pixel XL
Honor	Android	Honor 9
Honor	Android	Honor 8 pro
Honor	Android	Honor 7X
Honor	Android	Honor 9 lite
Honor	Android	Honor 5X
Honor	Android	Honor 6X
Honor	Android	Honor 7 lite
Honor	Android	Honor 7
Honor	Android	Honor 6A
Honor	Android	Honor 8
Honor	Android	Honor 4C
Honor	Android	Honor 5C
Honor	Android	Honor 6
Honor	Android	Honor 6+
HTC	Android	One
HTC	Android	One Mini
HTC	Android	ONE X
HTC	Android	Desire HD
HTC	Android	Desire S
HTC	Android	Desire X
HTC	Android	DESIRE C
HTC	Android	One V
HTC	Android	Rhyme
HTC	Android	one S
HTC	Android	Sensation Z 710e
HTC	Android	One M9 (HIMA)
HTC	Android	Desire 601
HTC	Android	DESIRE 310
HTC	Android	DESIRE 200
HTC	Android	DESIRE 510

HTC	Android	U11
HTC	Android	10
HTC	Android	U Ultra
HTC	Android	U Play
HTC	Android	Desire 12
HTC	Android	U11 life
HTC	Android	One (M8)
HTC	Android	U11+
HTC	Android	One (M9)
HTC	Android	A9
HTC	Android	Desire 626
HTC	Android	Desire 816
HTC	Android	Desire 820
HTC	Android	One Max
Huawei	Android	G510
Huawei	Android	Ascend P6
Huawei	Android	Ascend P7
Huawei	Android	Y530-U00
Huawei	Android	Ascend
Huawei	Android	ASCEND G6
Huawei	Android	ASCEND G510
Huawei	Android	ASCEND G620S
Huawei	Android	ASCEND Y550
Huawei	Android	Media Pad
Huawei	Android	RIO - L01
Huawei	Android	A21L
Huawei	Android	P7-L10
Huawei	Android	Y5 Bee (Y560)
Huawei	Android	G8 Rock-L01 RIO L11 SS
Huawei	Android	P8 lite
Huawei	Android	P9
Huawei	Android	P9 lite
Huawei	Android	P20 pro
Huawei	Android	P20
Huawei	Android	P20 lite
Huawei	Android	P10 plus
Huawei	Android	P10
Huawei	Android	P10 lite
Huawei	Android	Mate 10 pro
Huawei	Android	Mate 10 lite
Huawei	Android	P9 plus
Huawei	Android	Mate 9
Huawei	Android	Mate 8
Huawei	Android	Mate 7
Huawei	Android	Nova
Huawei	Android	P8
Huawei	Android	P7
Huawei	Android	P smart
Huawei	Android	Y6 II

Huawei	Android	Y7
Huawei	Android	P9 lite mini
Huawei	Android	Y6 pro
Huawei	Android	Y5 II
Huawei	Android	Y5
Lenovo	Android	A6000
Lenovo	Android	TAB 2 A10-70
Lenovo	Android	Vibe P1m
Lenovo	Android	2010
Lenovo	Android	A6010
Lenovo	Android	YOGA Tab 3
LG	Android	Optimus L3 II
LG	Android	G flex
LG	Android	Nexus 4
LG	Android	Optimus L5 II
LG	Android	Optimus 4x HD
LG	Android	P970
LG	Android	Optimus L7
LG	Android	Optimus L9
LG	Android	Optimus 3D
LG	Android	Optimus Black
LG	Android	H410
LG	Android	C70 Spirit LTE (H440n)
LG	Android	LG G4
LG	Android	LG G2 (D802)
LG	Android	LG G2 MINI
LG	Android	LG Nexus 5X bullhead (H791)
LG	Android	LG G Flex D955
LG	Android	LG G3 D855
LG	Android	LG K8
LG	Android	LG G5
LG	Android	LG K10
LG	Android	LG K4
LG	Android	LG X screen
LG	Android	LG D390N F60
LG	Android	LG SPIRIT
LG	Android	LG G PAD
LG	Android	V30
LG	Android	V30s
LG	Android	G6
LG	Android	G3
LG	Android	Q6
LG	Android	X power 2
LG	Android	V10
Motorola	Android	Moto Z
Motorola	Android	Moto Z play
Motorola	Android	Phab 2 Pro
Motorola	Android	K5 Note
Motorola	Android	Moto M

Motorola	Android	Moto C
Motorola	Android	K6
Motorola	Android	Moto E4+
Motorola	Android	Moto G5
Motorola	Android	Moto E4
Motorola	Android	Moto G5S+
Motorola	Android	Moto G5+
Motorola	Android	Moto X4
Motorola	Android	Moto Z2 play
Nokia	Android	Nokia 8
Nokia	Android	Nokia 6
Nokia	Android	Nokia 5
Nokia	Android	Nokia 3
Nokia	Android	Nokia 2
OnePlus	Android	5T
OnePlus	Android	5
OnePlus	Android	3T
OnePlus	Android	3
OnePlus	Android	2
Prestigio	Android	Prestigio MultiPad 7.0 Prime 3G
Prestigio	Android	PRESTIGIO MULTIPAD 4
Samsung	Android	Galaxy Young
Samsung	Android	S3 mini
Samsung	Android	S3
Samsung	Android	GT N7100
Samsung	Android	GT P3100
Samsung	Android	GT P5200
Samsung	Android	Galaxy Tab 4
Samsung	Android	Galaxy Note 3
Samsung	Android	P5100
Samsung	Android	Galaxy Tab 3 Light
Samsung	Android	Galaxy S Plus
Samsung	Android	Galaxy FAME
Samsung	Android	Galaxy S3 mini
Samsung	Android	Galaxy Ace 2
Samsung	Android	GALAXY ACE 4
Samsung	Android	Galaxy S plus
Samsung	Android	Galaxy Note
Samsung	Android	Galaxy Note II
Samsung	Android	Tab 2 7.0
Samsung	Android	Galaxy S
Samsung	Android	Galaxy Tab 2 10.1
Samsung	Android	S2
Samsung	Android	Galaxy Core Prime
Samsung	Android	GALAXY S5
Samsung	Android	Galaxy S6
Samsung	Android	Galaxy S6 edge
Samsung	Android	Galaxy S4 GT-I9505
Samsung	Android	Galaxy Tab A 9.7 SM-T555

Samsung	Android	Galaxy S7
Samsung	Android	Galaxy S7 edge
Samsung	Android	Galaxy A3
Samsung	Android	Galaxy A5
Samsung	Android	GALAXY Xcover 3
Samsung	Android	Galaxy Tab S2 9.7 LTE
Samsung	Android	GALAXY TAB 3
Samsung	Android	GALAXY NOTE 7
Samsung	Android	Galaxy S8
Samsung	Android	Galaxy S8+
Samsung	Android	Galaxy S9
Samsung	Android	Galaxy S9+
Samsung	Android	Note 4
Samsung	Android	Note 5
Samsung	Android	Note 8
Samsung	Android	Galaxy A8
Samsung	Android	Galaxy J7
Samsung	Android	Galaxy J5
Samsung	Android	Galaxy J3
Samsung	Android	Galaxy Xcover 3
Samsung	Android	Galaxy Xcover 4
Sony	Android	Sony Ericson Xperia ARC S
Sony	Android	Sony Xperia Ray
Sony	Android	Sony Xperia GO
Sony	Android	Sony Xperia C1905
Sony	Android	Sony Xperia S
Sony	Android	Sony Xperia SP
Sony	Android	Sony Xperia TIPO
Sony	Android	Sony Xperia T
Sony	Android	Sony Xperia Tablet Z
Sony	Android	Sony Xperia Z
Sony	Android	Sony Xperia Z1
Sony	Android	Sony Xperia Z2
Sony	Android	Sony Ericsson Xperia ARC S
Sony	Android	Sony Ericsson Live with Walkman
Sony	Android	Sony Ericsson Xperia Neo
Sony	Android	Sony Ericsson Xperia S
Sony	Android	Sony Ericsson Xperia U
Sony	Android	Sony Xperia L
Sony	Android	Sony Xperia P
Sony	Android	Sony Xperia Ray
Sony	Android	Sony Xperia Tablet Z
Sony	Android	Sony xperia SP
Sony	Android	Sony Xperia Z5 Premium (E6853)
Sony	Android	Sony Xperia Z2 Sirius (I1-II) D6503
Sony	Android	Sony Xperia Z1 Honami (C6903)
Sony	Android	Sony Xperia Z1 compact Amami (D5503)
Sony	Android	Sony Xperia E1

Sony	Android	Sony Xperia E3
Sony	Android	Sony Xperia M5
Sony	Android	Sony Xperia E5
Sony	Android	Sony Xperia X
Sony	Android	Sony Xperia XZ
Sony	Android	Sony Xperia XA
ZTE	Android	ZTE BLADE Q
ZTE	Android	ZTE Blade III
ZTE	Android	ZTE GRAND X IN
ZTE	Android	ZTE Light Tab 2
Xiaomi	Android	Mi Mix
Xiaomi	Android	Mi Mix 2 SE
Xiaomi	Android	Mi Mix 2
Xiaomi	Android	Redmi Note 5
Xiaomi	Android	Mi Max 2
Xiaomi	Android	Redmi Note 4
Xiaomi	Android	Redmi 5 plus
Xiaomi	Android	Mi A1
Xiaomi	Android	Redmi Note 3 Pro
Xiaomi	Android	Redmi 3S
Xiaomi	Android	Redmi 4 pro
Xiaomi	Android	Redmi 5
Xiaomi	Android	Redmi 4
Xiaomi	Android	Redmi Note 5A prime
Xiaomi	Android	Redmi 4x
Xiaomi	Android	Redmi 4A
Xiaomi	Android	Redmi Note 2
Xiaomi	Android	Redmi Note 3
Xiaomi	Android	Mi 6
Xiaomi	Android	Mi 5
Xiaomi	Android	Mi Max
Xiaomi	Android	Mi 4
Xiaomi	Android	Mi 5s